

**ZONE3 IR Remote code** for AVR2808CI

Code: Kaseikyo-code

2007/5/30

maker code								parity	Genre1	Genre2	Data code								parity	Function													
4	5				2				3	0	4	6	29	30	31	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	
0	0	1	0	1	0	1	0	0	1	0	0	1	1	0	0	0	0	0	0	0	0	0	0	0	0	1	1	0	0	1	0	0	ZONE POWER ON
0	0	1	0	1	0	1	0	0	1	0	0	1	1	0	1	1	1	0	0	0	0	0	0	0	0	1	1	0	1	1	0	0	ZONE POWER OFF
0	0	1	0	1	0	1	0	0	1	0	0	1	1	0	0	0	1	1	0	1	0	0	0	0	0	1	0	1	0	1	1	0	PHONO
0	0	1	0	1	0	1	0	0	1	0	0	1	1	0	1	0	0	1	1	0	1	0	0	0	0	1	0	1	1	1	1	0	TUNER
0	0	1	0	1	0	1	0	0	1	0	0	1	1	0	0	0	1	1	0	1	0	0	0	0	1	0	1	0	0	0	1	0	CD
0	0	1	0	1	0	1	0	0	1	0	0	1	1	0	1	1	0	0	1	1	0	0	0	0	1	0	1	0	1	0	1	0	TAPE-1
0	0	1	0	1	0	1	0	0	1	0	0	1	1	0	0	0	1	1	0	1	0	0	1	0	0	1	1	0	1	0	1	1	DVD
0	0	1	0	1	0	1	0	0	1	0	0	1	1	0	1	0	0	1	1	0	1	0	0	1	0	1	1	0	1	1	1	1	HDP(VDP)
0	0	1	0	1	0	1	0	0	1	0	0	1	1	0	0	1	1	0	1	1	0	0	1	0	0	1	1	0	1	0	0	1	TV/CBL
0	0	1	0	1	0	1	0	0	1	0	0	1	1	0	1	1	0	0	1	1	0	0	1	0	0	1	1	0	1	0	1	0	SAT(DBS)
0	0	1	0	1	0	1	0	0	1	0	0	1	1	0	1	1	1	0	0	1	1	0	0	0	0	1	0	1	0	0	1	0	NET/USB(AUX-1)
0	0	1	0	1	0	1	0	0	1	0	0	1	1	0	0	1	0	1	1	0	1	0	0	0	1	0	1	0	0	0	1	1	SAT TU(XM-Radio)
0	0	1	0	1	0	1	0	0	1	0	0	1	1	0	1	1	0	1	0	1	0	0	0	0	1	0	1	0	1	0	1	1	DTU(HD-Radio)
0	0	1	0	1	0	1	0	0	1	0	0	1	1	0	1	0	1	1	0	1	0	1	1	0	0	1	0	1	1	1	0	1	IPOD
0	0	1	0	1	0	1	0	0	1	0	0	1	1	0	1	0	1	1	0	1	0	0	1	0	0	1	1	0	1	1	0	0	VCR(VCR-1)
0	0	1	0	1	0	1	0	0	1	0	0	1	1	0	0	1	1	0	1	0	0	1	0	0	1	1	0	1	0	0	0	0	DVR-1(VCR-2)
0	0	1	0	1	0	1	0	0	1	0	0	1	1	0	1	0	0	1	1	0	1	0	0	1	0	1	1	0	1	1	1	1	V.AUX-1
0	0	1	0	1	0	1	0	0	1	0	0	1	1	0	0	1	1	1	0	1	0	0	0	1	1	1	0	0	0	1	0	1	MASTER VR UP
0	0	1	0	1	0	1	0	0	1	0	0	1	1	0	1	0	0	1	1	0	1	0	0	0	1	0	0	0	0	0	0	1	MASTER VR DOWN
0	0	1	0	1	0	1	0	0	1	0	0	1	1	0	0	1	1	1	0	1	0	0	0	1	0	0	0	0	1	1	1	0	MASTER VR MUTE
0	0	1	0	1	0	1	0	0	1	0	0	1	1	0	0	1	0	1	1	0	1	0	0	0	0	1	0	1	0	1	0	1	TUNING UP
0	0	1	0	1	0	1	0	0	1	0	0	1	1	0	1	1	0	1	1	0	1	0	0	0	0	1	0	1	0	0	1	1	TUNING DOWN
0	0	1	0	1	0	1	0	0	1	0	0	1	1	0	0	0	1	1	1	0	1	0	0	0	1	0	1	1	1	0	1	0	PRESET CH UP
0	0	1	0	1	0	1	0	0	1	0	0	1	1	0	1	0	1	1	1	0	1	0	0	0	1	0	1	0	1	0	1	0	PRESET CH DOWN
0	0	1	0	1	0	1	0	0	1	0	0	1	1	0	0	1	1	1	0	1	0	1	1	0	0	1	0	1	1	0	0	1	PRESET CH SHIFT
0	0	1	0	1	0	1	0	0	1	0	0	1	1	0	0	0	1	1	1	1	1	0	0	0	0	0	1	1	1	1	1	0	Play/Pause
0	0	1	0	1	0	1	0	0	1	0	0	1	1	0	1	0	0	1	1	1	1	0	0	0	0	0	1	0	1	1	0	0	Stop
0	0	1	0	1	0	1	0	0	1	0	0	1	1	0	0	1	1	1	1	1	0	0	0	0	0	1	1	0	1	0	1	0	Pause
0	0	1	0	1	0	1	0	0	1	0	0	1	1	0	1	1	0	0	1	1	1	0	0	0	0	0	1	0	0	1	0	0	Skip Minus
0	0	1	0	1	0	1	0	0	1	0	0	1	1	0	0	0	1	1	1	1	0	0	0	0	0	0	1	1	1	0	0	0	Skip Plus
0	0	1	0	1	0	1	0	0	1	0	0	1	1	0	1	1	0	1	1	1	0	0	1	1	0	0	1	1	0	0	1	1	ipod dock FAVORITE
0	0	1	0	1	0	1	0	0	1	0	0	1	1	0	0	1	1	0	1	1	1	0	0	1	1	0	1	1	1	0	1	0	REPEAT
0	0	1	0	1	0	1	0	0	1	0	0	1	1	0	1	1	0	1	1	1	0	0	1	0	1	1	0	1	0	1	0	1	RANDOM