

Thank you for purchasing DENON's product. When you operate the unit, please read the owner's manual and this sheet.

☞ page 35 : **Correction**

### Option Setup

Make various other settings.

● **Menu tree** ●

- Manual Setup
- Option Setup
- 1 Amp Assign
- 2 Volume Control
- 3 Source Delete
- 4 GUI
- 5 Quick Select Name
- 6 Trigger Out 1
- 7 Trigger Out 2
- 8 Digital Out
- 9 Remote ID
- 10 2Way Remote
- 11 Dimmer
- 12 Setup Lock
- 13 Maintenance Mode
- 14 Firmware Update
- 15 Add New Feature

☞ page 37 : **Correction**

### 14 Firmware Update

Update the firmware of the receiver.

### Check for Update

You can check for firmware updates. You can also check approximately how long it will take to complete an update.

### Start

Execute the update process.

When updating starts, the power indicator becomes red and the GUI screen is shut down. The amount of update time which has elapsed is displayed.

When updating is complete the power indicator becomes green and normal status is resumed.

※ If the display reads as shown below, check the settings and network environment, then update again.

Display	Description
Updating failed	Updating failed.
Login failed	Failure to log into server.
Server is busy	Server is busy. Wait a while then try again.
Connection fail	Failure connecting to server.

☞ page 37 : **Additional Information**

### 15 Add New Feature

Display the new functions (payment required) which can be purchased for downloading to the AVR-4308CI and upgrade.

When you purchase a new function and register your user information, "Registered" is displayed on this menu and you can proceed with the upgrade.

### Upgrade

Execute the upgrade process.

When updating starts, the power indicator becomes red and the GUI screen is shut down. The amount of update time which has elapsed is displayed.

When updating is complete the power indicator becomes green and normal status is resumed.

※ If the upgrade is not successful, an error message identical to those in "Firmware Update" will appear on the display, check the settings and network environment, then update again.

### Notes concerning use of "Firmware Update" and "Add New Feature"

- In order to use these functions, you must have the correct system requirements and settings for a broadband Internet connection.
- Do not turn off the power until updating or upgrading is completed.
- Even with a broadband connection to the Internet, approximately 1 hour is required for the updating/upgrading procedure to be completed. Once updating/upgrade starts, normal operations on the AVR-4308CI cannot be performed until updating/upgrading is completed. Furthermore, updating/upgrading the firmware may reset the backup data for the parameters, etc., set for the AVR-4308CI.



Information regarding the "Firmware Update" function and "Add New Feature" will be announced on the DENON web site each time related plans are defined.